

Ports used for IP phone connectivity and audio				Forward to
Service	Port Number	Protocol	Device to forward to	IP Address
IP Phone Interface	6000	TCP/UDP	MCP	
MGI Card	30000-30031	TCP/UDP	MGI/OAS	
IP Phone (Open on phone side)	9000,9001	RTP(UDP)	MGI/OAS	
VoIP Networking	6100	TCP	MCP	
SIP	5060	TCP/UDP	MCP	
SIP2	5070	TCP/UDP	MGI/OAS	
WIP	8000,8001	TCP/UDP	MCP	
WIP2	10000,10001	TCP/UDP	MCP	
MPS	40000-40031	TCP/UDP	MGI/OAS	

Ports used for OfficeServ Manager Connectivity				
Service	Port Number	Protocol	Device to forward to	
PCMMC/OSM	5000,5003,5200	TCP	MCP	
IT	5080,5090,5003	TCP	MCP	

Ports used for Hyperterminal to SVMi				
Service	Port Number	Protocol	Device to forward to	
Hyperterminal	23	TCP	SVMi	

Public IP Address