



Bulletin No.: 2007- 10

October 12, 2007

## OfficeServ™ 7100 Installation Tool Cross Reference Chart

The purpose of this Technical Bulletin is to cross reference the Installation Tool menu with its corresponding Man-Machine Code (MMC).

The left side column is the corresponding MMC and the right column is where that particular MMC can be found in the Installation Tool.

| <b>MMC</b> | <b>Program Name</b>            | <b>Installation Tool</b>          |
|------------|--------------------------------|-----------------------------------|
| <b>100</b> | <b>STATION LOCK</b>            | <b>5.15.1</b>                     |
| <b>101</b> | <b>CHANGE USER PASSCODE</b>    | <b>5.15.1</b>                     |
| <b>102</b> | <b>CALL FORWARD</b>            | <b>5.15.6</b>                     |
| <b>103</b> | <b>SET ANSWER MODE</b>         | <b>5.15.2</b>                     |
| <b>104</b> | <b>STATION NAME</b>            | <b>2.4.2, 5.15.1</b>              |
| <b>105</b> | <b>STATION SPEED DIAL</b>      | <b>5.15.7</b>                     |
| <b>106</b> | <b>STATION SPEED DIAL NAME</b> | <b>5.15.7</b>                     |
| <b>108</b> | <b>STATION STATUS</b>          | <b>2.4.1, 2.8.0, 6.2.1</b>        |
| <b>109</b> | <b>DATE/TIME DISPLAY</b>       | <b>5.15.2</b>                     |
| <b>110</b> | <b>STATION ON/OFF</b>          | <b>5.15.2, 5.15.3,<br/>5.15.4</b> |
| <b>111</b> | <b>KEYSET RING TONE</b>        | <b>5.15.5</b>                     |
| <b>112</b> | <b>ALARM CLOCK</b>             | <b>5.15.8</b>                     |
| <b>114</b> | <b>STATION VOLUME</b>          | <b>5.15.5</b>                     |
| <b>115</b> | <b>SET PROGRAMMED MESSAGE</b>  | <b>5.15.9</b>                     |
| <b>116</b> | <b>ALARM REMINDER</b>          | <b>5.15.8</b>                     |
| <b>117</b> | <b>TEXT MESSAGE</b>            | <b>5.15.10</b>                    |
| <b>118</b> | <b>CONFERENCE GROUP</b>        | <b>5.15.11</b>                    |
| <b>119</b> | <b>CALLER ID/ ANI DISPLAY</b>  | <b>5.15.3</b>                     |
| <b>120</b> | <b>LARGE LCD OPTION</b>        | <b>5.15.12</b>                    |

## OfficeServ 7100 Installation Tool Cross Reference

| <b>MMC</b> | <b>Program Name</b>                   | <b>Installation Tool</b>                    |
|------------|---------------------------------------|---------------------------------------------|
| <b>121</b> | <b>STATION LANGUAGE ASSIGNMENT</b>    | <b>5.15.3</b>                               |
| <b>122</b> | <b>SPOT INFO SPD</b>                  | <b>5.15.2</b>                               |
| <b>125</b> | <b>EXECUTIVE PRESENT STATE</b>        | <b>5.15.13</b>                              |
| <b>199</b> | <b>SHOW LICENSE STATUS</b>            | <b>2.1.4</b>                                |
| <b>201</b> | <b>CHANGE CUSTOMER PASSCODE</b>       | <b>5.13.1</b>                               |
| <b>202</b> | <b>CHANGE FEATURE PASSCODE</b>        | <b>5.13.1</b>                               |
| <b>203</b> | <b>ASSIGN UA DEVICE</b>               | <b>5.13.1</b>                               |
| <b>204</b> | <b>COMMON BELL CONTROL</b>            | <b>2.2.1</b>                                |
| <b>205</b> | <b>ASSIGN LOUD BELL</b>               | <b>2.2.1</b>                                |
| <b>206</b> | <b>BARGE-IN TYPE</b>                  | <b>5.13.1</b>                               |
| <b>208</b> | <b>ASSIGN RING TYPE</b>               | <b>2.5.7</b>                                |
| <b>209</b> | <b>ASSIGN ADD-ON MODULE</b>           | <b>4.2.3</b>                                |
| <b>210</b> | <b>CUSTOMER ON/OFF PER TENANT</b>     | <b>3.1.1, 3.3.4, 5.2.1, 5.2.2, 5.14.1-8</b> |
| <b>211</b> | <b>DOOR RING ASSIGNMENT</b>           | <b>3.2.7</b>                                |
| <b>214</b> | <b>DISA ALARM RINGING STATION</b>     | <b>5.13.1</b>                               |
| <b>217</b> | <b>STATION PAIR</b>                   | <b>4.2.1</b>                                |
| <b>218</b> | <b>RELAY TYPE</b>                     | <b>2.2.1</b>                                |
| <b>219</b> | <b>TRAFFIC REPORT PRINTOUT</b>        | <b>5.13.1</b>                               |
| <b>223</b> | <b>ISDN SERVICE TYPE</b>              | <b>2.5.7</b>                                |
| <b>224</b> | <b>AUDIO PROMPT</b>                   | <b>5.13.1</b>                               |
| <b>300</b> | <b>CUSTOMER ON/OFF PER STATION</b>    | <b>2.4.2, 2.5.2-7</b>                       |
| <b>301</b> | <b>ASSIGN STATION COS</b>             | <b>4.7.1</b>                                |
| <b>302</b> | <b>PICKUP GROUPS</b>                  | <b>2.5.1</b>                                |
| <b>303</b> | <b>ASSIGN EXECUTIVE/SECRETARY</b>     | <b>4.2.2</b>                                |
| <b>304</b> | <b>ASSIGN EXTENSION/TRUNK USE</b>     | <b>5.1.2, 5.1.3</b>                         |
| <b>305</b> | <b>ASSIGN FORCED CODE</b>             | <b>4.5.1</b>                                |
| <b>306</b> | <b>HOT LINE</b>                       | <b>2.5.5</b>                                |
| <b>308</b> | <b>ASSIGN BACKGROUND MUSIC SOURCE</b> | <b>2.5.6</b>                                |
| <b>309</b> | <b>ASSIGN STATION MUSIC ON HOLD</b>   | <b>2.4.2</b>                                |
| <b>310</b> | <b>LCR CLASS OF SERVICE</b>           | <b>2.4.2</b>                                |

Samsung Telecommunications America  
Business Communication Systems  
1301 East Lookout Drive  
Richardson, TX 75082

## OfficeServ 7100 Installation Tool Cross Reference

| <b>MMC</b> | <b>Program Name</b>                  | <b>Installation Tool</b>                                   |
|------------|--------------------------------------|------------------------------------------------------------|
| <b>312</b> | <b>ALLOW CID / ANI</b>               | <b>2.5.1</b>                                               |
| <b>314</b> | <b>ASSIGN STATIONS/STATION USE</b>   | <b>2.5.1, 5.1.4</b>                                        |
| <b>315</b> | <b>CUSTOMER SET RELOCATION</b>       | <b>6.3.6</b>                                               |
| <b>316</b> | <b>PRESET FORWARD NO ANSWER</b>      | <b>2.5.4</b>                                               |
| <b>320</b> | <b>BRANCH GROUP</b>                  | <b>2.5.1</b>                                               |
| <b>321</b> | <b>SEND CLI NUMBER</b>               | <b>2.4.3</b>                                               |
| <b>326</b> | <b>RBT MSG</b>                       | <b>2.5.1</b>                                               |
| <b>400</b> | <b>CUSTOMER ON/OFF PER TRUNK</b>     | <b>2.6.2, 2.6.5, 3.2.2</b>                                 |
| <b>401</b> | <b>C.O./PBX LINE</b>                 | <b>2.6.2</b>                                               |
| <b>402</b> | <b>TRUNK DIAL TYPE</b>               | <b>2.6.1</b>                                               |
| <b>403</b> | <b>TRUNK TOLL CLASS</b>              | <b>4.8.5</b>                                               |
| <b>404</b> | <b>TRUNK NAME</b>                    | <b>2.4.2</b>                                               |
| <b>405</b> | <b>TRUNK TELEPHONE NUMBER</b>        | <b>2.6.1</b>                                               |
| <b>406</b> | <b>TRUNK RING ASSIGNMENT</b>         | <b>3.2.1</b>                                               |
| <b>408</b> | <b>ASSIGN TRUNK MOH SOURCE</b>       | <b>2.4.2, 3.2.2</b>                                        |
| <b>409</b> | <b>TRUNK STATUS READ</b>             | <b>2.4.1, 2.8.0, 6.2.1</b>                                 |
| <b>410</b> | <b>ASSIGN DISA TRUNK</b>             | <b>3.2.2</b>                                               |
| <b>414</b> | <b>ASSING CALLER ID / ANI TRUNKS</b> | <b>2.6.5</b>                                               |
| <b>415</b> | <b>REPORT TRUNK ABANDON DATA</b>     | <b>2.6.2</b>                                               |
| <b>417</b> | <b>TRK TMC GAIN</b>                  | <b>5.4.4</b>                                               |
| <b>418</b> | <b>TRUNK GAIN CONTROL</b>            | <b>5.4.3</b>                                               |
| <b>419</b> | <b>DISTINCTIVE RINGING</b>           | <b>2.4.2</b>                                               |
| <b>420</b> | <b>ANI / DNIS OPTIONS</b>            | <b>5.13.1</b>                                              |
| <b>421</b> | <b>TRUNK COS</b>                     | <b>4.7.1</b>                                               |
| <b>422</b> | <b>COST RATE</b>                     | <b>5.12.1</b>                                              |
| <b>430</b> | <b>PRI CONTROL</b>                   | <b>2.6.8</b>                                               |
| <b>432</b> | <b>CONNECTION STATUS</b>             | <b>6.2.1</b>                                               |
| <b>438</b> | <b>16 TRUNK GAIN</b>                 | <b>5.4.6</b>                                               |
| <b>500</b> | <b>SYSTEM-WIDE COUNTERS</b>          | <b>5.14.3, 5.14.4,<br/>5.14.6</b>                          |
| <b>501</b> | <b>SYSTEM TIMERS</b>                 | <b>3.1.1, 3.3.4, 5.2.1,<br/>5.2.2,<br/>5.5.0, 5.14.1-8</b> |

Samsung Telecommunications America  
Business Communication Systems  
1301 East Lookout Drive  
Richardson, TX 75082

## OfficeServ 7100 Installation Tool Cross Reference

| <b>MMC</b> | <b>Program Name</b>                         | <b>Installation Tool</b>              |
|------------|---------------------------------------------|---------------------------------------|
| <b>502</b> | <b>STATION-WIDE TIMERS</b>                  | <b>2.5.4, 2.5.5, 2.5.7</b>            |
| <b>503</b> | <b>TRUNK-WIDE TIMER</b>                     | <b>2.6.1, 2.6.3, 2.6.5,<br/>3.2.2</b> |
| <b>504</b> | <b>PULSE MAKE/BREAK RATIO</b>               | <b>5.5.0</b>                          |
| <b>505</b> | <b>ASSIGN DATE AND TIME</b>                 | <b>2.1.3</b>                          |
| <b>506</b> | <b>TONE CADENCE</b>                         | <b>5.7.1</b>                          |
| <b>507</b> | <b>ASSIGN RING PLAN TIME</b>                | <b>4.3.1</b>                          |
| <b>510</b> | <b>SLI RING CADENCE</b>                     | <b>5.7.3</b>                          |
| <b>511</b> | <b>MESSAGE WAITING LAMP CADENCE</b>         | <b>5.5.0</b>                          |
| <b>512</b> | <b>HOLIDAY ASSIGNMENT</b>                   | <b>4.3.2</b>                          |
| <b>515</b> | <b>ASSIGN DAYLIGHT SAVINGS DATE</b>         | <b>2.1.3</b>                          |
| <b>600</b> | <b>ASSIGN OPERATOR GROUP</b>                | <b>5.13.1</b>                         |
| <b>601</b> | <b>ASSING STATION GROUP</b>                 | <b>4.1.1</b>                          |
| <b>602</b> | <b>STATION GROUP NAME</b>                   | <b>4.1.1</b>                          |
| <b>603</b> | <b>ASSIGN TRUNK GROUP</b>                   | <b>4.1.2</b>                          |
| <b>604</b> | <b>ASSIGN INTERNAL PAGE ZONES</b>           | <b>4.1.3</b>                          |
| <b>605</b> | <b>ASSIGN EXTERNAL PAGE ZONE</b>            | <b>4.1.3</b>                          |
| <b>606</b> | <b>ASSIGN SPEED BLOCK</b>                   | <b>2.1.1, 2.1.5, 2.5.1</b>            |
| <b>607</b> | <b>UCD OPTIONS</b>                          | <b>4.6.1</b>                          |
| <b>608</b> | <b>ASSIGN REVIEW BLOCK</b>                  | <b>2.5.6</b>                          |
| <b>609</b> | <b>CALL LOG BLOCK</b>                       | <b>2.5.6</b>                          |
| <b>611</b> | <b>ALLOW TEXT MESSAGING</b>                 | <b>2.5.6</b>                          |
| <b>612</b> | <b>GROUP CONFERENCE ALLOW</b>               | <b>2.5.6</b>                          |
| <b>614</b> | <b>SET A STATION / C.O. LINE CALL GROUP</b> | <b>5.1.1</b>                          |
| <b>615</b> | <b>MGI GROUP</b>                            | <b>4.1.4</b>                          |
| <b>616</b> | <b>MGI USER</b>                             | <b>2.2.2</b>                          |
| <b>701</b> | <b>ASSIGN COS CONTENTS</b>                  | <b>4.7.2</b>                          |
| <b>702</b> | <b>TOLL DENY TABLE</b>                      | <b>4.8.1</b>                          |
| <b>703</b> | <b>TOLL ALLOWANCE TABLE</b>                 | <b>4.8.2</b>                          |
| <b>704</b> | <b>ASSIGN WILD CHARACTER</b>                | <b>4.8.3</b>                          |
| <b>705</b> | <b>ASSIGN SYSTEM SPPED DIAL</b>             | <b>4.4.0</b>                          |
| <b>707</b> | <b>AUTHORIZATION CODE</b>                   | <b>4.5.3</b>                          |

Samsung Telecommunications America  
Business Communication Systems  
1301 East Lookout Drive  
Richardson, TX 75082

## OfficeServ 7100 Installation Tool Cross Reference

| <b>MMC</b> | <b>Program Name</b>                      | <b>Installation Tool</b> |
|------------|------------------------------------------|--------------------------|
| <b>708</b> | <b>ACCOUNT CODE</b>                      | <b>4.5.2</b>             |
| <b>709</b> | <b>TOLL PASS CODE/SPECIAL CODE TABLE</b> | <b>4.8.4</b>             |
| <b>710</b> | <b>LCR DIGIT TABLE</b>                   | <b>3.1.2</b>             |
| <b>711</b> | <b>LCR TIME TABLE</b>                    | <b>3.1.3</b>             |
| <b>712</b> | <b>LCR ROUTE TABLE</b>                   | <b>3.1.4</b>             |
| <b>713</b> | <b>LCR MODIFY DIGIT TABLE</b>            | <b>3.1.5</b>             |
| <b>714</b> | <b>DID NUMBER AND NAME TRANSLATION</b>   | <b>3.2.3</b>             |
| <b>715</b> | <b>PROGRAMMED STATION MESSAGE</b>        | <b>5.13.3</b>            |
| <b>717</b> | <b>MY AREA CODE</b>                      | <b>2.1.5</b>             |
| <b>718</b> | <b>UCD AGENT ID</b>                      | <b>4.6.2</b>             |
| <b>719</b> | <b>IDLE DISPLAY</b>                      | <b>5.13.4</b>            |
| <b>720</b> | <b>COPY KEY PROGRAMMING</b>              | <b>6.3.7</b>             |
| <b>721</b> | <b>SAVE STATION KEY PROGRAMMING</b>      | <b>6.3.8</b>             |
| <b>722</b> | <b>STATION KEY PROGRAMMING</b>           | <b>4.9.2</b>             |
| <b>723</b> | <b>SYSTEM KEY PROGRAMMING</b>            | <b>4.9.1</b>             |
| <b>724</b> | <b>DIAL NUMBERING PLAN</b>               | <b>2.4.1, 2.8.0</b>      |
| <b>727</b> | <b>SYSTEM VERSION DISPLAY</b>            | <b>2.1.1, 2.2.0</b>      |
| <b>728</b> | <b>CID / ANI TRANSLATION TABLE</b>       | <b>3.2.6</b>             |
| <b>729</b> | <b>RATE CALCULATION</b>                  | <b>5.6.3, 5.12.2</b>     |
| <b>730</b> | <b>COSTING DIAL PLAN</b>                 | <b>5.12.3</b>            |
| <b>740</b> | <b>VM CARD RESTART</b>                   | <b>2.1.6</b>             |
| <b>741</b> | <b>USER MAILBOX</b>                      | <b>5.9.1</b>             |
| <b>743</b> | <b>AUTO RECORD</b>                       | <b>5.9.2</b>             |
| <b>744</b> | <b>VM DAY / NIGHT</b>                    | <b>2.1.6</b>             |
| <b>745</b> | <b>WARNING DESTINATION</b>               | <b>2.1.6</b>             |
| <b>746</b> | <b>VM HALT</b>                           | <b>2.1.6</b>             |
| <b>747</b> | <b>VM ALARM</b>                          | <b>2.1.6</b>             |
| <b>748</b> | <b>ASSIGN VM MOH</b>                     | <b>2.2.3</b>             |
| <b>749</b> | <b>VM IN/OUT</b>                         | <b>2.2.3</b>             |
| <b>759</b> | <b>CLI RINGING</b>                       | <b>3.2.5</b>             |
| <b>763</b> | <b>IN DIGIT</b>                          | <b>3.1.6</b>             |

Samsung Telecommunications America  
Business Communication Systems  
1301 East Lookout Drive  
Richardson, TX 75082

## OfficeServ 7100 Installation Tool Cross Reference

| <b>MMC</b> | <b>Program Name</b>                      | <b>Installation Tool</b>           |
|------------|------------------------------------------|------------------------------------|
| <b>801</b> | <b>CHANGE TECHNICIAN PASSCODE</b>        | <b>2.1.5</b>                       |
| <b>802</b> | <b>CUSTOMER ACCESS MMC NUMBER</b>        | <b>5.13.2</b>                      |
| <b>804</b> | <b>SYSTEM I/O PARAMETER</b>              | <b>5.6.1</b>                       |
| <b>805</b> | <b>LEVEL &amp; GAIN</b>                  | <b>5.4.1</b>                       |
| <b>806</b> | <b>CARD PRE-INSTALL</b>                  | <b>2.2.0, 6.3.1</b>                |
| <b>807</b> | <b>ADJUST DIGITAL PHONE TONE QUALITY</b> | <b>5.4.2</b>                       |
| <b>810</b> | <b>HALT PROCESSING</b>                   | <b>6.3.3</b>                       |
| <b>811</b> | <b>RESET SYSTEM</b>                      | <b>6.3.1</b>                       |
| <b>812</b> | <b>SET COUNTRY</b>                       | <b>2.1.5</b>                       |
| <b>815</b> | <b>CUSTOMER DATABASE COPY</b>            | <b>2.1.5</b>                       |
| <b>816</b> | <b>CONFERENCE GAIN</b>                   | <b>5.4.1</b>                       |
| <b>820</b> | <b>ASSIGN SYSTEM LINK ID</b>             | <b>3.3.1</b>                       |
| <b>821</b> | <b>Q-SIG TRUNK</b>                       | <b>2.6.8</b>                       |
| <b>822</b> | <b>VIRTUAL STATION TYPE</b>              | <b>2.4.1, 2.8.0, 6.2.1</b>         |
| <b>823</b> | <b>NETWORK COS</b>                       | <b>4.7.3</b>                       |
| <b>824</b> | <b>NETWORK DIAL PLAN</b>                 | <b>3.3.2</b>                       |
| <b>825</b> | <b>NETWORK OPTIONS</b>                   | <b>3.3.4</b>                       |
| <b>826</b> | <b>CLOCK SOURCE</b>                      | <b>5.5.0</b>                       |
| <b>829</b> | <b>LAN PRINTER PARAMETER</b>             | <b>5.6.2</b>                       |
| <b>830</b> | <b>ETHERNET PARAMETERS</b>               | <b>2.1.2, 5.6.1</b>                |
| <b>831</b> | <b>MGI PARAMETERS</b>                    | <b>2.2.2</b>                       |
| <b>832</b> | <b>VOIP OUTBOUND DIGITS</b>              | <b>5.2.3, 5.2.4</b>                |
| <b>833</b> | <b>VOIP IP ADDRESS</b>                   | <b>5.2.5</b>                       |
| <b>834</b> | <b>H.232 OPTION</b>                      | <b>5.2.1</b>                       |
| <b>835</b> | <b>MGI DSP OPTION</b>                    | <b>5.2.9</b>                       |
| <b>836</b> | <b>H.323 GK OPTION</b>                   | <b>5.2.1, 5.2.6</b>                |
| <b>837</b> | <b>SIP OPTIONS</b>                       | <b>5.2.2</b>                       |
| <b>838</b> | <b>PRIVATE IP ADDRESS</b>                | <b>5.2.8</b>                       |
| <b>839</b> | <b>SIP USER</b>                          | <b>5.2.7</b>                       |
| <b>840</b> | <b>IP SET INFO</b>                       | <b>2.7.1, 5.2.11, 6.2.2</b>        |
| <b>841</b> | <b>SYSTEM IP OPTION</b>                  | <b>2.1.4, 5.2.10, 5.4.1, 5.6.1</b> |

Samsung Telecommunications America  
Business Communication Systems  
1301 East Lookout Drive  
Richardson, TX 75082

## OfficeServ 7100 Installation Tool Cross Reference

| <b>MMC</b> | <b>Program Name</b>             | <b>Installation Tool</b>          |
|------------|---------------------------------|-----------------------------------|
| <b>845</b> | <b>WLAN PARAMETERS</b>          | <b>5.3.1</b>                      |
| <b>846</b> | <b>WIP INFO</b>                 | <b>2.7.3, 6.2.5</b>               |
| <b>848</b> | <b>WLAN IP/MAC</b>              | <b>5.3.3</b>                      |
| <b>849</b> | <b>WLAN CONFIG</b>              | <b>5.3.1, 6.3.11<br/>WIPCLEAR</b> |
| <b>851</b> | <b>ALARM MONITORING</b>         | <b>2.1.5, 6.1.1, 6.3.9</b>        |
| <b>852</b> | <b>SYSTEM ALARM ASSIGNMENTS</b> | <b>5.8.1, 6.1.1</b>               |
| <b>853</b> | <b>MAINTENANCE BUSY</b>         | <b>2.4.2, 5.8.2</b>               |
| <b>854</b> | <b>DIAGNOSTIC TIME</b>          | <b>5.8.3</b>                      |
| <b>855</b> | <b>SYSTEM HARDWARE OPTIONS</b>  | <b>2.1.1, 2.2.0</b>               |
| <b>856</b> | <b>TECH PROGRAMMING LOGS</b>    | <b>6.1.2</b>                      |
| <b>857</b> | <b>VIRTUAL CABINETS</b>         | <b>2.3.0, 6.3.2</b>               |
| <b>859</b> | <b>HARDWARE VERSION</b>         | <b>2.2.0, 2.2.1</b>               |
| <b>861</b> | <b>SYSTEM OPTION</b>            | <b>2.1.3, 2.1.5, 3.3.4</b>        |
| <b>863</b> | <b>ACCESS NUMBER</b>            | <b>3.3.3</b>                      |
| <b>865</b> | <b>FAN POWER CONTROL</b>        | <b>2.2.0</b>                      |
| <b>890</b> | <b>PORT CLEAR</b>               | <b>6.3.5</b>                      |
| <b>901</b> | <b>SYSTEM CODING</b>            | <b>2.1.5</b>                      |
| <b>902</b> | <b>DIAGNOSTIC ITEMS</b>         | <b>5.8.3</b>                      |
| <b>990</b> | <b>MP MEMORY DUMP</b>           | <b>6.3.4</b>                      |

## OfficeServ 7100 Installation Tool Cross Reference

**The following are available via the phone but not the Installation tool.**

| <b>MMC</b>    | <b>Program</b>                   |
|---------------|----------------------------------|
| <b>MMC107</b> | <b>KEY EXTENDER</b>              |
| <b>MMC200</b> | <b>OPEN CUSTOMER PROGRAMMING</b> |
| <b>MMC313</b> | <b>COPY STATION/TRUNK USE</b>    |
| <b>MMC317</b> | <b>TIME/COST DISPLAY OPTION</b>  |
| <b>MMC407</b> | <b>FORCED TRUNK RELEASE</b>      |
| <b>MMC412</b> | <b>ASSIGN TRUNK SIGNAL</b>       |
| <b>MMC424</b> | <b>CARD RESTART</b>              |
| <b>MMC700</b> | <b>COPY COS CONTENTS</b>         |
| <b>MMC706</b> | <b>SYSTEM SPEED DIAL BY NAME</b> |
| <b>MMC725</b> | <b>SMDR OPTIONS</b>              |
| <b>MMC800</b> | <b>ENABLE TECHNICIAN PROGRAM</b> |
| <b>MMC818</b> | <b>PROGRAM DOWNLOAD</b>          |
| <b>MMC819</b> | <b>FILE CONTROL</b>              |
| <b>MMC850</b> | <b>SHOW SYSTEM RESOURCES</b>     |

*If you have any questions about this or any other Technical Support bulletins please contact Samsung Technical Support by phone at 1-800-737-7008 or by email at: [BCS.Support@Samsung.com](mailto:BCS.Support@Samsung.com)*